



8620,8600 Mounting Instructions

1. Component Chart :

- ① 8620 Lock ② A0060-8600 Roller ③ A0059-8600 Profile ④ A0061-8600 End Cap
- ⑤ A0062 Spline ⑥ A0063 Silencer ⑦ A0058 Bottom Profile ⑧ A0057 Top Profile

2. (1) Locate ① ~ ⑤ on the location as indicated below

- (2) Place ⑤ on the bottom of the glass door , then insert onto the ③ profile
- (3) Fasten ⑦ & ⑧ with screws onto the wooden frame

3. Drill a hole on the rear door to let the lock plunge through it.

Item no.: 8600

