

IFAM S4MK ja R4MK koodiriippulukko master-avaimella

Näppärä koodiriippulukko ohjelmoitavalla koodilla, joka voidaan avata myös erikseen tilattavalla master-avaimella. Master-avaimella voidaan myös selvittää lukon voimassa oleva käyttäjäkoodi.

Koodin selvitys master-avaimella

Master avain viedään lukkoon ja lukko aukaistaan. Kiekkoja pyöritetään myötäpäivään, kunnes kiekko pysähtyy oikean numeron kohdalla.


Uuden koodin asettaminen

Lukossa on tehtaalla valmiiksi asetettu koodi 0-0-0-0 ja sen voi muuttaa lukon ollessa auki asennossa. Sankaa käännetään 90 astetta ja painetaan alaspäin ja samalla valitaan uusi koodi.


- Lukko S4MK: Master-avain tilattava erikseen (tuotenro. 211059)
- Lukko R4MK: Master-avain tilattava erikseen (tuotenro. 211060)

SETTING YOUR OWN COMBINATION

Your new resettable combination padlock is preset to open at 0-0-0-0, even though dials may be positioned at other numbers.



Step 1:
Turn the dials and align the numbers to preset combination 0-0-0-0 so they are clearly visible inside the 'windows'.




Step 2:
Pull out the shackle.



Step 3:
Turn the shackle counterclockwise 90°.



Step 4:
Press the shackle down all the way, hold it firmly and turn the dials to your own desired combination. Do not let go of the shackle before completely setting the desired combination.



Step 5:
Release the shackle and return it back to the original position. Your new personal combination is now ready to use. Keep your combination in a safe and accessible place for future reference.

HOW TO CHECK THE MISSING COMBINATION

When forget the number, you can use the emergency key to open the lock and decode the number.



Step 1:
Use the emergency key.



Step 2:
Turn the key 90 degree clockwise to open the lock and release shackle.



Step 3:
Rotate the dials, till it stop (do this process for all dials).



Step 4:
Then you got the previous setting combination.



Step 5:
After you found the opening combination. Please, remember to close the cab then take out the key. The lock can be used again.

Note: Use the key only for an emergency access.

