

FACTORY CODE 000


HOW TO CHANGE THE CODE

When the lock is in the open position, insert a pin in to the tiny round hole on the side of the lock, and set the new code by turning the dial.

Please keep the new code, because once you forget it, it can't be opened.



hole to change code



1. There are 3 digits for this lock along with 1000 combinations.

2. The lock is set by default in the factory using "000" as code.

3. How to reset the password:

(1) When the lock is in the open position, insert a pin with 2mm diameter in to the tiny round hole on the lock, and reset the new password by turning the dial.

Please keep the new password, because once you forget it, it can't be opened.